

Preface

Thank you for purchasing ARA388/KD386 series constant pressure water supply frequency inverter.

This manual describes how to use inverter properly. Please read it carefully before installation, operation, maintenance and inspection. Besides, please use the product after understanding the safety precautions.


Precautions


- In order to describe the product's details, the drawings presented in this instruction are sometimes shown without covers or protective guards. When using the product, please make sure to install the cover or protective guard as specified firstly, and operate the products in accordance with the instructions.
- Since the drawings in this manual are represented examples, some are subject to differ from delivered products.
- This manual may be modified when necessary because of improvement of the product, modification or changes in specifications. Such modifications are denoted by a revised manual No.
- If you want to order the manual due to loss or damage, please contact our company agents in each region or our company customer service center directly.
- If there is still any problem during using the products, please contact our company customer service center directly.


Contents


Chapter 1 Safety and preclusions.....	- 3 -
Chapter 2 Product Information.....	- 5 -
2.1 Model Description	- 5 -
2.2 Selection Guide	- 5 -
2.3 Technical Specifications	- 8 -
2.4 External and keypad dimensions	- 9 -
Chapter 3 Installation and wiring	- 14 -
3.1 System wiring connection	- 14 -
3.2 Installation	- 15 -
3.3 KD388 disassemble and install diagram	- 16 -
3.4 Typical diagram	- 16 -
3.5 Instructions of main circuit terminals	- 18 -
3.6 Description of Control Terminals Function.....	- 19 -
3.7 Principle of wiring connection	- 20 -
Chapter 4 Keypad operation instruction.....	- 22 -
4.1 diagram of keypad	- 22 -
4.2 functions description of keypad.....	- 23 -
4.3 Functions description of indicators.....	- 23 -
4.4 Operation.....	- 24 -
Chapter 6 MODBUS Communication Protocol.....	- 34 -
6.1 About Protocol	- 34 -
6.2 Application Method	- 34 -
6.3 Bus Structure.....	- 34 -
6.4 Interfaces and wiring connection	- 35 -
6.5 Protocol Description	- 36 -
6.6 Communication Data Structure	- 36 -
6.7 Parameters address list	- 37 -
Chapter 7 Troubles Shooting	- 39 -
7.1 Fault and Trouble Shooting.....	- 39 -
7.2 Common Faults and Solutions	- 46 -
Chapter 8 Commissioning	- 48 -
8.1 One pump system	- 48 -
8.2 Two pumps system	- 50 -
8.3 Three pumps system	- 53 -
8.4 Four pumps system	- 56 -

Chapter 1 Safety and preclusions

 Danger	<ul style="list-style-type: none"> ● Forbid to operate with wet hands. ● Forbid to carry out wiring distribution operation when the power source is not completely cut off. ● Please do not open the cover or carry out wiring distribution operation when ARA/ARA386 is electrified and operating. Or otherwise, there will be danger of electric shock. ● Carry out wiring distribution and inspection operation after cutting off power source for 10 minutes. Or otherwise, there will be danger of electric shock. ● ARA388/ARA386 will automatically start if its power source is cut off in operation and then connected. Please make sure operation safety before electrifying the converter. Or otherwise, there may be chances of personal injury accident.
---	--

 Warning	<ul style="list-style-type: none"> ● Please do not install ARA388/ARA386 whose components are damaged or missing to avoid personal injury and property loss. ● The connection between the terminal of main circuit and the cable must be tight. Or otherwise, there may be damage to KD388/KD386 due to poor contact. ● Make sure that ARA388/ARA386 is installed on the fireproof materials (such as metal) to avoid fire disaster. □ Make sure there is no foreign matter entering ARA388/ARA386, such as electricity wire fragment, soldering tin, zinc-iron sheet to avoid short circuit, which may lead to ARA388/ARA386 being burned.
--	---


 Obligatory	<ul style="list-style-type: none"> ● Please configure non-fuse breaker or breaker with earth leakage protection used for protection the circuit at the input power source side of ARA388/ARA386 in order to avoid the expansion of accident caused by fault in the intelligent constant-pressure water-supply frequency converter. ● Carry out wiring distribution and inspection operation after cutting off power source for 10 minutes. Or otherwise, there will be danger of electric shock.
---	--

 Caution	<ul style="list-style-type: none"> ● Please cut off the power source of ARA388/ARA386 which is not used for a long time to prevent it from being damaged by foreign matter or other factors, or even fire disaster. ● Do not install capacitance or surge current absorber (such as piezoresistor) at the output side, because the output voltage of KD388/KD386 is PWM pulse wave. Or otherwise, KD388/KD386 will be tripped and the power elements will be damaged. If the capacitance or surge current absorber is installed at the output side, please must disassemble it.
--	---

Chapter 2 Product Information

2.1 Model Description

ARA388 – 00075 T 4



2.2 Selection Guide

2.2.1 ARA388

Inverter Model	Motor		Rated Input Current (A)	Rated Output Current (A)
	kW	HP		
1AC 220V±15%				
ARA388-00040S2	0.4	0.5	5.4	2.3
ARA388-00075S2	0.75	1	8.2	4
ARA388-00150S2	1.5	2	14	7
ARA388-00220S2	2.2	3	24	9.6
3AC 220V±15%				
ARA388-00004T2	0.4	0.5	3.4	2.3
ARA388-00075T2	0.75	1	5	4
ARA388-00150T2	1.5	2	9.5	7
ARA388-00220T2	2.2	3	11	9.6
ARA388-00400T2	4.0	5	20.5	17
3AC 460V±15%				
ARA388-00075T4	0.75	1	3.4	2.8
ARA388-00150T4	1.5	2	5	4.4
ARA388-00220T4	2.2	3	6.5	5.8
ARA388-00400T4	4.0	5	11	10
ARA388-00550T4	5.5	7.5	14.6	13
ARA388-00750T4	7.5	10	20.5	17

2.2.2 ARA386

Inverter Model	Motor		Rated Input Current (A)	Rated Output Current (A)
	kW	HP		
1AC 220V±15%				
ARA386-00040S2	0.4	0.5	5.4	2.3
ARA386-00075S2	0.75	1	8.2	4
ARA386-00150S2	1.5	2	14	7
ARA386-00220S2	2.2	3	24	9.6
ARA386-00400S2	4.0	5	30	17
ARA386-00550S2	5.5	7.5	45	25
3AC 220V±15%				
ARA386-00040T2	0.4	0.5	3.4	2.3
ARA386-00075T2	0.75	1	5	4
ARA386-00150T2	1.5	2	9.5	7
ARA386-00220T2	2.2	3	11	9.6
ARA386-00400T2	4.0	5	20.5	17
ARA386-00550T2	5.5	7.5	27	25
ARA386-00750T2	7.5	10	35	32
ARA386-01100T2	11	15	46.5	45
ARA386-01500T2	15	20	62.5	60
ARA386-01850T2	18.5	25	76	75
ARA386-02200T2	22	30	92	90
ARA386-03000T2	30	40	113	110
ARA386-03700T2	37	50	157	152
ARA386-04500T2	45	60	180	176
ARA386-05500T2	55	75	214	210
ARA386-07500T2	75	100	307	304
3AC 380V±15%				
ARA386-00075T4	0.75	1	3.4	2.8
ARA386-00150T4	1.5	2	5	4.4
ARA386-00220T4	2.2	3	6.5	5.8
ARA386-00400T4	4.0	5	11	10
ARA386-00550T4	5.5	7.5	14.6	13
ARA386-00750T4	7.5	10	20.5	17
ARA386-01100T4	11	15	26	25


ARA386-01500T4	15	20	35	32
ARA386-01850T4	18.5	25	38.5	37
ARA386-02200T4	22	30	46.5	45
ARA386-03000T4	30	40	62	60
ARA386-03700T4	37	50	76	75
ARA386-04500T4	45	60	92	90
ARA386-05500T4	55	75	113	110
ARA386-07500T4	75	100	157	152
ARA386-09000T4	90	125	180	176
ARA386-11000T4	110	150	214	210
ARA386-13200T4	132	175	260	253
ARA386-16000T4	160	210	310	304
ARA386-18500T4	185	250	365	350
ARA386-20000T4	200	260	385	380
ARA386-22000T4	220	300	430	426
ARA386-25000T4	250	330	485	465
ARA386-28000T4	280	370	531	520
ARA386-31500T4	315	420	620	585
ARA386-35500T4	350	470	665	650
ARA386-40000T4	400	530	785	725
ARA386-45000T4	450	600	880	820

2.3 Technical Specifications

Item	Technical Index	Specification
Input	Input voltage	1AC/3AC 220V±15%, 3AC 460V±15%
	Input frequency	50/60Hz±5%
Control functions	Output voltage	0~rated input voltage
	Output frequency	0~600Hz
	Operation command mode	Keypad control Terminal control Serial communication control (Modbus)
	Overload capacity	150% / 60s, 180% / 10s, 200% / 1s.
	Built-in PID	Built-in PID control function, special for constant pressure water supply.
Input/output terminals	Input terminals	Programmable digital input: 5 multifunctional inputs 2 programmable analog input: VI: 0~10V CI: 4~20mA
	Output terminals	Refer to typical wiring for details
	Communication terminals	RS485 communication interface, support MODBUS-RTU communication protocol
Display	LED display	Display frequency setting, output frequency, output voltage, output current, etc. Two lines display.
Environment	Ambient temperature	-10°C~40°C, without direct sunshine.
	Humidity	90%RH or less (non-condensing)
	Altitude	≤1000M: output rated power, >1000M: output derated.
	Storage temperature	-20°C~60°C

2.4 External and keypad dimensions


2.4.1 ARA388




Unit (mm)

Model	W	H	D
ARA388-00040S2	120	196.2	112.1
ARA388-00075S2			
ARA388-00150S2			
ARA388-00220S2			
ARA388-00075T4			
ARA388-00150T4			
ARA388-00220T4			
ARA388-00400T4	150	241	142.5
ARA388-00550T4			
ARA388-00750T4			


2.4.2 ARA386 (0.75~2.2kW)




Front view



Dimensions of keypad



Side view




Dimensions of keypad bracket


Unit (mm)

Model	W	W1	H	H1	D
ARA386-00040S2	85.5	74	142	132	113
ARA386-00075S2					
ARA386-00150S2					
ARA386-00220S2	101	92	152	143	117
ARA386-00075T2					
ARA386-00150T2					
ARA386-00220T2					
ARA386-00075T4					
ARA386-00150T4					
ARA386-00220T4					



2.4.3 ARA386 (4.0~7.5kW)




Front view





Dimensions of keypad



Side view




Dimensions of keypad bracket




Unit (mm)

Model	W	W1	H	H1	D
ARA386-00400S2	130	115	264	244	153.5
ARA386-00400T2					
ARA386-00400T4					
ARA386-00550T4					
ARA386-00750T4					


2.4.4 ARA386 ($\geq 11\text{kW}$)



Front view



Side view




Dimensions of keypad bracket

Unit (mm)

Model	W	W1	H	H1	D	Aperture
ARA386-00550S2	210	160	375	362.5	196	7
ARA386-00550T2						
ARA386-00750T2						
ARA386-01100T4						
ARA386-01500T4						
ARA386-01850T4	285	238	440	424	206	9
ARA386-01100T2						
ARA386-01500T2						
ARA386-01850T2						
ARA386-02200T4						
ARA386-03000T4	385	260	600	580	267.7	10
ARA386-03700T4						
ARA386-02200T2						
ARA386-03000T2						
ARA386-04500T4						
ARA386-05500T4	413	293	659	635	327	12
ARA386-03700T2						
ARA386-04500T2						
ARA386-07500T4						
ARA386-09000T4						
ARA386-05500T2	480	369	849	822.5	389	12
ARA386-07500T2						
ARA386-11000T4						
ARA386-13200T4						
ARA386-16000T4						
ARA386-18500T4	650	420	1060	1030	380.5	12
ARA386-20000T4						
ARA386-22000T4						
ARA386-25000T4						
ARA386-28000T4						
ARA386-31500T4	800	520	1361.5	1300	393	16
ARA386-35500T4						
ARA386-40000T4						
ARA386-45000T4						

Chapter 3 Installation and wiring


3.1 System wiring connection




- (1) ARA388/KD386 build-in a lightning protection device, it will be self-protected for induction thunder. But for some special places where the thunder happens very frequently, it is better to add an additional lightning protection device.
- (2) If the installation place's altitude is higher than 1000m, the output power of ARA388/ARA386 will be derated.

3.2 Installation

1, ARA388 is designed to install on the water pump directly, it has the below two installation types:




Horizontal type



Vertical type

2, ARA386 is designed to install on the wall or in the control cabinet.




On the wall




In the control cabinet

3.3 ARA388 disassemble and install diagram




3.4 Typical diagram


3.4.1 ARA388




3.4.2 ARA386 (0.4~7.5kW)



3.4.3 ARA386 ($\geq 11\text{kW}$)



3.5 Instructions of main circuit terminals

Terminal	Description
R, T	Connect to single-phase AC power
R, S, T	Connect to three-phase AC power
(+), (-)	Reserved terminals for external brake unit ($>18.5\text{kW}$)
P, PB	Reserved terminals for braking resistor ($0.4\text{kW}\sim7.5\text{kW}$)
(+), PB	Reserved terminals for braking resistor ($11\text{kW}\sim18.5\text{kW}$)
P1, (+)	Reserved terminals for external DC reactor
U, V, W	Connect to three phase motor
	Ground connection terminal

3.6 Description of Control Terminals Function

Type	Terminal Symbol	Terminal Name	Function Description
Power Supply	10V	10V power supply	Provide +10V power supply for external units, and the maximum output current is 100mA.
	24V	24V power supply	Provide +24V power supply for external units. It is generally used as the operating power supply for the external pressure transducer. The maximum output current is 150mA.
Analog Input	VI	Analog input terminal 1	1. Input range: DC 0V~10V. 2. Input impedance: 6.8kΩ.
	CI	Analog input terminal 2	1. Input range: 4mA~20Ma 2. Input impedance: 500Ω.
	GND	Zero potential	Zero potential reference of 10V and 24V ($\leq 7.5kW$)
	ACM	Zero potential	Zero potential reference of 10V ($\leq 7.5kW$)
	DCM	Zero potential	Zero potential reference of 24V ($> 7.5kW$)
Digital Input	MI1	Digital input 1	1. Optical coupling isolation, compatible with dual polarity input 2. Input impedance: 2.4kΩ 3. Voltage range for level input: 9V~30V
	MI2	Digital input 2	
	MI3	Digital input 3	
	MI4	Standby	
	MI5	Standby	
Digital Output	MO1		Correspond common terminal is GND ($\leq 7.5kW$). Correspond common terminal is DCM ($> 7.5kW$). External connection voltage range: 0~24V Output current range: 0mA~50mA
	MO2		
	MO3		
	MO4		
Relay Output 1	TB-TC	Normally close terminal	Driving capacity: AC 250V/3A, DC 30V/1A
	TB-TA	Normally open terminal	
Relay Output 2	TA1-TB1	Normally open terminal	Driving capacity: AC 250V/3A DC 30V/A
RS485	S+	RS485+	Communication interface of Modbus, it is suggested to use twisted-pair cable or shielded cable.
	S-	RS485-	


3.7 Principle of wiring connection

(1) Power cables

- ◆ Please select the cables size (diameter) properly based on the power rating, current and electrician standard.
- ◆ It is suggested to install a MCB (Main Circuit Breaker) between power supply and R, S, T terminals, and the MCB should not be interfered by high frequency signals.
- ◆ The power cables must keep safe distance with control cables, don't put them in one wire casing.
- ◆ Never connect the power supply to U, V, W terminals.
- ◆ The output power cables cannot touch any point of frequency inverter's metal case, otherwise it will cause grounding short-circuited.
- ◆ The power cables must keep safe distance with other devices.
- ◆ If the cables' length between motor and frequency inverter is longer than 50 meters (220V inverter) or 100 meters (380V inverter), it must install an additional output reactor in the system.
- ◆ If the cables' length between motor and frequency inverter is long, please reduce the carrier frequency, if the carrier frequency is bigger, the leakage current of higher harmonic on the cable will be bigger, which will bring bad effect to frequency inverter and other devices.


(2) Control cables

- ◆ Don't put the power cables and control cables in one wire casing, otherwise it will cause interferences.
- ◆ Please use shield cables for control circuit, and it is suggested to use 1mm² shield cables.
- ◆ Don't make the analog signal cables' length longer than 20 meters.




(3) Ground connection


- ◆ The grounding resistor should be less than $100\ \Omega$.
- ◆ The grounding cables length is the shorter the better.
- ◆ Please don't make frequency inverters' grounding point separated with other big power equipment (like electric welder and other large-scale mechanical devices)
- ◆ Please make correct grounding as below diagram



A: Correct



B: Wrong



C: Wrong



Chapter 4 Keypad operation instruction

4.1 diagram of keypad

4.1.1. ARA388 keypad



4.1.2 ARA386 keypad











0.75~2.2kW



≥4kW

4.2 functions description of keypad

Button	Name	Function
	Programming key	Entry and exit of primary menu
	Confirmation key	Progressively enter menu, and confirm parameters
	Run key	Start ARA388/ARA386 under keyboard control mode (F1-00=0)
	Stop / Reset	Stop ARA388/ARA386 in running status and reset operation in fault alarm status.
	Increase key	Increase the setting value or function codes
	Decrease key	Decrease the setting value or function codes
	Left shift key	Left shift while parameters changing, shift the parameters display on main LED (Top LED)
	Right shift key	Right shift while parameters changing, shift the parameters display on main LED (Top LED)

4.3 Functions description of indicators

Indicators	Function
Mpa	When LED display the pressure of pipe line, the indicator will light-on
A	When LED display the output current, the indicator will light-on
Hz	When LED display the running frequency, the indicator will light-on
Auto	Light-on: Auto operation mode light flicker: stand by
Com	When multiple KD388 inter connected successfully, the indicator will light-on
Manu	ARA388 under Manual operation mode
SLP	ARA388 under sleep mode

4.4 Operation

4.4.1 Brief introduction

ARA388/ARA386 has 8 operation buttons on the keypad; customers can achieve system monitoring, parameters modification easily.


Under auto operation mode, press [▲] or [▼] button for more than 3 seconds to set the target pressure, press [◀] or [▶] button can shift different display of real time pressure, current etc.

Under manual operation mode, press [▲] or [▼] button can change the running frequency.

4.4.2 Operation example

To change F0-24=1 (Restore factory setting)

Operation process	LED display	
	Main LED (UP)	Slave LED (DOWN)
Before operation	0.00	0.000
Press “PRGM” button for 3 seconds	F0	
Press “ENTER”	F0-00	1
Press [▲] button to F0-24	F0-24	0
Press “ENTER” to read	0	0
Press [▲] to 1	1	0
Press “ENTER” to confirm	F0-00	1
Press “PRGM” button two times to return back	0.00	0.000



Chapter 5 Function Parameter List

“○” Means the parameter can be modified at stop and running status.

“◎” Means the parameter cannot be modified at the running status.

“●” Means the parameter is the real detection value which cannot be modified.

Function code	Name	Detailed instruction	Factory default	Modify
F0 Group: Basic Functions				
F0-00	Operation mode	0: Manual: ARA388/ARA386 can be operated manually 1: Single pump system 2: Multiple pumps system 3: General: ARA388/ARA386 is used as a general frequency inverter	1	◎
F0-01	Setting pressure	Range: F0-07~F0-05 Set the real requested pressure, the unit is Mpa, 1Mpa=10bar.	0.4Mpa	○
F0-02	Pump wake-up pressure	Range: 0.0%~100.0% It is the percentage of setting frequency (F0-01). For example, if F0-01=0.5Mpa, and set F0-02=90%, that means the wake up pressure is 0.45Mpa.	80.0%	○
F0-03	Pressure feedback channel	0: 0~10V, voltage signal, it is usually connect with remote pressure gage; 1: 4~20Ma, current signal, connect with pressure transducer.	0	◎
F0-04	Maximum measure range of pressure transducer	Range: 0.000~6.000Mpa Set it according to the real pressure transducer's measure range. Note: it must be set correctly, otherwise, may cause the water supply pressure incorrect.	1.600MPa	◎

Function code	Name	Detailed instruction	Factory default	Modify
F0-05	Upper limitation pressure	Range: F0-01~F0-04 While the pipe line pressure higher than this value, ARA388/ARA386 will stop, it is used to protect the pressure transducer.	1.5MPa	⊙
F0-06	Time delay of upper limitation pressure	Range: 0~6000s Response time of upper limitation pressure, set 0 to disable this protection.	3s	○
F0-07	Lower limitation pressure	Range: 0.000~F0-01 While the pipe line pressure less than this value, ARA388/ARA386 stops. To check whether the pipe line is broken.	0.05Mpa	⊙
F0-08	Time delay of lower limitation pressure	Range: 0~6000s Response time of lower limitation pressure, set 0 to disable this protection.	300s	○
F0-09	Lack of water protection	0~1000s 0: No protection	60s	⊙
F0-10	Motor rated current	0.1~1000.0kW	Model depend	⊙
F0-11	Motor rated current	0.01~655.35A (≤55kW) 0.1~6553.5A (> 55kW)	Model depend	⊙
F0-12	Pressure calibration	Range: 0.000~1.000 To adjust the difference between pressure gauge and ARA388/ARA386 displays pressure. If display pressure bigger than real pressure, it needs to reduce this value. Vice versa.	0.500	○
F0-13	Acceleration time	0.1~6500.0s	Model depend	○
F0-14	Deceleration time	0.1~6500.0s	Model depend	○

Function code	Name	Detailed instruction	Factory default	Modify
F0-15	Pressure maintaining detection time	3~6000s	30s	○
F0-16	Pressure maintaining detection coefficient	0: Disable 1~10: Increase this value will get faster pressure maintaining response.	2	○
F0-17	Dormancy frequency	0.00 ~ F1-23	30.00Hz	○
F0-18	Auto-reset times of pressure abnormal	0 ~ 1000 Auto-reset times of pressure abnormal. Set 0 means no auto-reset, set 1000 means no times limitation of auto-reset.	1000	○
F0-19	Interval of pressure abnormal auto-reset	0~60000min Pressure abnormal recovery time	10min	○
F0-20	Time delay of rust-proof (freeze-proof)	3~60000min	1500min	○
F0-21	Rust-proof (freeze-proof) duration	0: Disable rust-proof (freeze-proof) function. 0~6000s	10s	○
F0-22	Running frequency of rust-proof (freeze-proof)	0.00 ~ F1-23	30.00Hz	○
F0-23	User password	0000~9999	0000	○
F0-24	Parameters initialization	0: no action 1: Initialize parameters to default setting	0	◎
F0-25	Pumps alternate time	Range: 0~60000min In multiple pumps system, when this pump needs to be alternated as master pump, F0-25 is to set the running time as master pump, when	300min	○

Function code	Name	Detailed instruction	Factory default	Modify
		time arrive, it switches to next pump as master. When set F0-25=0, this pump will only work as slave pump.		
F1 Group: Control Parameters				
F1-00	Running command source	0: keypad 1: terminal (digital input signal) 2: communication (Modbus)	0	○
F1-01	Selection of frequency source	0: set by keypad [▲] and [▼] buttons 1: VI (0~10V) 2: CI (4~20mA) 3: communication (Modbus) 9: PID	9	◎
F1-02	Running direction	0: same direction 1: reverse direction	0	○
F1-03	Stop mode	0: deceleration to stop 1: coast to stop	0	○
F1-04	Main LED display parameters	0000~01FF Bit00: running frequency Bit01: DC Bus voltage Bit02: output current Bit03: setting pressure Bit04: real time pressure Bit05: current power-on time Bit06: current running time Bit07: temperature of KD388/KD386 Bit08: accumulated running time	001D	○
F1-05	Slave LED display parameters	0: running frequency 1: DC Bus voltage 2: output current 3: setting pressure 4: real time pressure 5: current power-on time	4	○

Function code	Name	Detailed instruction	Factory default	Modify
		6: current running time 7: temperature of ARA388/ARA386 8: accumulated running time		
F1-06	Protection of power supply voltage	70.0%~100.0%	100%	○
F1-07	Fault auto-reset times	0~20	3	○
F1-08	Fault auto-reset interval	0.1~100.0s	20.0s	○
F1-09	Baud rate	0: 300BPS 1: 600BPS 2: 1200BPS 3: 2400BPS 4: 4800BPS 5: 9600BPS 6: 19200BPS 7: 38400BPS 8: 57600BPS 9: 115200BPS	5	○
F1-10	Data format	0: No parity check (8-N-2) 1: Even parity check (8-E-1) 2: Odd parity check (8-O-1) 3: No parity check (8-N-1)	0	○
F1-11	Address of this ARA388/ARA386	Range: 1~4 In multiple pumps system, Set 1 or 2, this pump will be master pump; Set 3 or 4, this pump will be slave pump. In one system, the addresses of different inverters cannot be set the same.	1	○
F1-12	Communication delay time	0ms ~ 20ms	2ms	○
F1-13	Communication timeout time	0.0 (invalid) 0.1s ~ 60.0s	0.0s	○
F1-14	MI1 terminal function	0: No function	1	◎
F1-15	MI2 terminal function	1: Forward (FWD)	0	◎
F1-16	MI3 terminal function	2: Reverse (REV)	0	◎

Function code	Name	Detailed instruction	Factory default	Modify
F1-17	Reserved	3: Running command switch 4: Forward Jog (FJOG) 5: Reverse Jog (RJOG) 6: Terminal UP 7: Terminal DOWN 8: Coast to stop 9: Fault reset (RESET) 10: Pause running 11: External fault (normal open) input	0	⊙
F1-18	MO1 output function (Open collector output)	0: No output 1: Inverter is running	0	○
F1-19	Relay 1 output function (TA, TB, TC)	2: Fault output 3: Zero-speed running	2	○
F1-20	MO2 output function (Open collector output)	4: Inverter is ready to run 5: VI > CI	0	○
F1-21	MO3 / Relay 2 (TAI, TB1) output function	6: Frequency upper limit arrival 7: Dormancy frequency arrival	0	○
F1-22	MO4 output function (Open collector output)	8: Under voltage 9: Frequency 1 arrival 10: Frequency 2 arrival 11: Reverse running 12: Over temperature alarm 13: Fault output (output only fault stop) 14: Reserved 15: Output current over limit	0	
F1-23	Frequency upper limit	10.00~100.00Hz	50.00Hz	⊙
F1-24	Carrier frequency	0.5~15.0kHz	Model depend	○
F1-25	Frequency detection value 1	0.00Hz~F1-23	50.00Hz	○
F1-26	Frequency detection amplitude 1	0.0~100.0%	0.0%	○

Function code	Name	Detailed instruction	Factory default	Modify
F1-27	Frequency detection value 2	0.00Hz~F1-23	0.00Hz	○
F1-28	Frequency detection amplitude 2	0.0~100.0%	0.0%	○
F1-29	MO1 output delay time	0.0s~3600.0s	0.0s	○
F1-30	Relay 1 (TA, TB, TC) output delay time	0.0s~3600.0s	0.0s	○
F1-31	MO2 output delay time	0.0s~3600.0s	0.0s	○
F1-32	MO3 / Relay 2 (TAI, TB1) output delay time	0.0s~3600.0s	0.0s	○
F1-33	MO4 output delay time	0.0s~3600.0s	0.0s	○
F1-34	Output terminal valid status selection	0: positive logic 1: negative logic Unit bit: MO1 Tens bit: relay 1 Hundreds bit: MO2 Thousand bit: MO3 / relay 2 Ten thousand bit: MO4	00000	○
F1-35	Pre-set frequency of manual operation mode	0.00Hz~F1-23	20.00Hz	○
F1-36	Auto restart selection after power recovery	0: No action 1: Auto restart	1	◎
F2 Group: Fault record				
F2-00	The first fault type		—	●
F2-01	The second fault type		—	●
F2-02	The third (latest) fault type		—	●
F2-03	Frequency at the third (latest) fault	—	—	●

Function code	Name	Detailed instruction	Factory default	Modify
F2-04	Current at the third (latest) fault	—	—	●
F2-05	DC Bus voltage at the third (latest) fault	—	—	●
F2-06	Input terminal's status at the third (latest) fault	—	—	●
F2-07	Output terminal's status at the third (latest) fault	—	—	●
F2-08	ARA388/386 status at the third (latest) fault	—	—	●
F2-09	Power-on time at the third (latest) fault	—	—	●
F2-10	Running time at the third (latest) fault	—	—	●
F2-11	Frequency at the second fault	—	—	●
F2-12	Current at the second fault	—	—	●
F2-13	DC Bus voltage at the second fault	—	—	●
F2-14	Input terminal's status at the second fault	—	—	●
F2-15	Output terminal's status at the second fault	—	—	●
F2-16	ARA388/386 status at the second fault	—	—	●
F2-17	Power-on time at the second fault	—	—	●
F2-18	Running time at the second fault	—	—	●
F2-19	Frequency at the first fault	—	—	●

Function code	Name	Detailed instruction	Factory default	Modify
F2-20	Current at the first fault	—	—	●
F2-21	DC Bus voltage at the first fault	—	—	●
F2-22	Input terminal's status at the first fault	—	—	●
F2-23	Output terminal's status at the first fault	—	—	●
F2-24	ARA388/386 status at the first fault	—	—	●
F2-25	Power-on time at the first fault	—	—	●
F2-26	Running time at the first fault	—	—	●
U0 Group: Monitoring Parameters				
U0-00	Running frequency		Hz	●
U0-01	DC bus voltage		V	●
U0-02	Output current		A	●
U0-03	Setting pressure		MPa	●
U0-04	Real time feedback pressure		MPa	●
U0-05	Power-on time		Min	●
U0-06	Running time		Min	●
U0-07	Temperature		°C	●
U0-08	Accumulated running time		Min	●

Chapter 6 MODBUS Communication Protocol

ARA388/ARA386 series inverter provides RS485 communication interface, and adopts MODBUS communication protocol. User can realize centralized monitoring through PC/PLC, host computer, and also can set inverter's operating commands, modify or read function parameters, read operating status and fault information, etc.

6.1 About Protocol

This serial communication protocol defines the transmission information and use format in the series communication. It includes the formats of master-polling, broadcast and slave response frame, and master coding method with the content including slave address (or broadcast address), command, transmitting data and error checking. The response of slave adopts the same structure, including action confirmation, returning the data and error checking etc. If slave takes place the error while it is receiving the information or cannot finish the action demanded by master, it will send one fault signal to master as a response.

6.2 Application Method

The inverter could be connected into a "Single-master & Multi-slaves" PC/PLC control network with RS485 bus.

6.3 Bus Structure

(1) Interface mode

RS485


(2) Transmission mode

There provide asynchronous series and half-duplex transmission mode. At the same time, just one can send the data and the other only receives the data between master and slave. In the series asynchronous communication, the data is sent out frame by frame in the form of message.


(3) Topological structure

In Single-master Multi-slave system, the setup range of slave address is 0 to 247. 0 refers to broadcast communication address. The address of slave must be exclusive in the network. That is basic condition of MODBUS communication.

a. Connect with PC



b. Connect with PLC




6.4 Interfaces and wiring connection

ARA388/386 series inverter provides S+ and S- interfaces for Modbus communication.


There are two kinds of communication type suitable for Modbus connection;

(1) Daisy chain connection



Notice: the **first one** and **last one inverters** should connect the terminal resistor.

(2) star connection



Notice: the **furthest one (25#)** and **second furthest one (7#)** inverters should connect the terminal resistor.

6.5 Protocol Description

ARA388/ARA386 series inverter communication protocol is a kind of asynchronous serial master-slave communication protocol. In the network, only one equipment (master) can build a protocol (Named as “Inquiry/Command”). Other equipment (slave) response “Inquiry/Command” of master only by providing the data, or doing the action according to the master’s “Inquiry/Command”. Here, master is Personnel Computer, Industrial control equipment or Programmable logical controller, and the slave is inverter or other communication equipment with the same communication protocol. Master not only can visit some slave separately for communication, but also sends the broadcast information to all the slaves. For the single “Inquiry/Command” of master, all of slaves will return a signal that is a response; for the broadcast information provided by master, slave needs not feedback a response to master.

6.6 Communication Data Structure

MODBUS protocol communication data format of ARA388/ARA386 series inverter is shown as

below: In RTU mode, the Modbus minimum idle time between frames should be no less than 3.5 bytes. The checksum adopts CRC-16 method. All data except checksum itself sent will be counted into the calculation. Please refer to section: CRC Check for more information. Note that at least 3.5 bytes of Modbus idle time should be kept and the start and end idle time need not be summed up to it.

The entire message frame must be transmitted as a continuous data stream. If a idle time is more than 1.5 bytes before completion of the frame, the receiving device flushes the incomplete message and assumes that the next byte will be the address field of a new message. Similarly, if a new message begins earlier than 3.5 bytes interval following a previous message, the receiving device

will consider it as a continuation of the previous message. Because of the frame's confusion, at last the CRC value is incorrect and communication fault will occur.

RTU frame format:

START	Transmission time of 3.5 bytes
Slave Address	Communication address : 0 to 249
Command Code	03H: Read slave parameters 06H: Write slave parameters
DATA (N-1)	Data: Function code parameter address, the number of function code parameter, Function code parameter, etc.
DATA (N-2)	
.....	
DATA 0	
CRC Low byte	Detection Value: CRC value
CRC High byte	
END	Transmission time of 3.5 bytes

6.7 Parameters address list

Classification	Address	Parameters	Description
Function codes	F000H ~ F025H	F0-00 ~ F0-25	F0 group parameters
	F100H ~ F136H	F1-00 ~ F1-36	F1 group parameters
	F200H ~ F226H	F2-00 ~ F2-26	F2 group parameters
	7000H ~ 7008H	U0-00 ~ U0-08	U0 group parameters
Control command (Write only)	2000H	0001	Forward run
		0002	Reverse run
		0003	Forward jog
		0004	Reverse jog
		0005	Coast to stop
		0006	Decelerate to stop
		0007	Fault reset
KD388/KD386 status (Read only)	3000H	0001	Forward running
		0002	Reverse running
		0003	Stop
Fault information (Read only)	8000H	0000	No fault
		0001	Reserved
		0002	Over current when acceleration

		0003	Over current when deceleration
		0004	Over current when constant speed running
		0005	Over voltage when acceleration
		0006	Over voltage when deceleration
		0007	Over voltage when constant speed running
		0008	Reserved
		0009	Under voltage
		000A	ARA388/386 Overload
		000B	Motor overload
		000C	Reserved
		000D	Output phase failure
		000E	IGBT overheat
		000F	External fault
		0010	Communication fault

Besides, due to EEPROM be frequently stored, it will reduce the lifetime of EEPROM. So in the communication mode, some function codes needn't be stored, only change the RAM value.

For F group parameters, to achieve this function, just change high bit F of the function code into 0.

Chapter 7 Troubles Shooting

7.1 Fault and Trouble Shooting

Fault Name	Converter short circuit protection
Fault Code	Err01
Reason	<ol style="list-style-type: none"> 1. Short-circuit or ground fault occurred at inverter output side 2. The cable connecting the motor with the inverter is too long 3. The module is over-heat 4. The cable connections inside the inverter are loosen 5. The control board is abnormal 6. The power board is abnormal 7. The IGBT module is abnormal
Solution	<ol style="list-style-type: none"> 1. Inspect whether motor damaged, insulation worn or cable damaged 2. Install a reactor or output filter 3. Check if the air duct is blocked and if the fan is in normal status, and resolve the existing problems 4. Make sure the cables are connected well 5, 6, 7. Ask for technical support

Fault Name	Over current when acceleration
Fault Code	Err02
Reason	<ol style="list-style-type: none"> 1. Short-circuit or ground fault occurred at inverter output side 2. Control mode is vector control but don't perform auto-tuning 3. The acceleration time is too short 4. The manual torque boost or V/f curve is not proper 5. The voltage is too low 6. Start the running motor 7. Load is added suddenly during the acceleration 8. Power selection of inverter is too small

Solution	<ol style="list-style-type: none"> 1. Inspect whether motor damaged, insulation worn or cable damaged 2. Identify the motor parameters 3. Increase the acceleration time 4. Adjust the manual torque boost or V/F curve 5. Make the voltage in the normal range 6. Select speed tracking start or start the motor till it stops 7. Cancel the sudden added load 8. Select bigger power inverter
----------	---

Fault Name	Over current when deceleration
Fault Code	Err03
Reason	<ol style="list-style-type: none"> 1. Short-circuit or ground fault occurred at inverter output side 2. The deceleration time is too short 3. The voltage is too low 4. Load is added suddenly during the deceleration
Solution	<ol style="list-style-type: none"> 1. Inspect whether motor damaged, insulation worn or cable damaged 2. Increase the deceleration time 3. Make the voltage in the normal range 4. Remove the sudden added load

Fault Name	Over-current when constant speed running
Fault Code	Err04
Reason	<ol style="list-style-type: none"> 1. Short-circuit or ground fault occurred at inverter output 2. The voltage is too low 3. Load is added suddenly during running 4. Power selection of inverter is too small
Solution	<ol style="list-style-type: none"> 1. Inspect whether motor damaged, insulation worn or cable damaged 2. Make the voltage in the normal range 3. Remove the sudden added load 4. Select bigger power inverter

Fault Name	Over-voltage when acceleration
Fault Code	Err05
Reason	<ol style="list-style-type: none"> 1. The input voltage is too high 2. There is an external force driving the motor to run during acceleration 3. The acceleration time is too short
Solution	<ol style="list-style-type: none"> 1. Make the voltage in the normal range 2. Remove the external force 3. Increase the acceleration time

Fault Name	Over-voltage when deceleration
Fault Code	Err06
Reason	<ol style="list-style-type: none"> 1. The input voltage is too high 2. There is an external force driving the motor to run during deceleration 3. The deceleration time is too short 4. Have not installed braking unit and braking resistor
Solution	<ol style="list-style-type: none"> 1. Make the voltage in the normal range 2. Remove the external force 3. Increase the deceleration time 4. Install braking unit and braking resistor

Fault Name	Over-voltage when constant speed running
Fault Code	Err07
Reason	<ol style="list-style-type: none"> 1. The input voltage is too high 2. There is external force driving the motor to run during the inverter running
Solution	<ol style="list-style-type: none"> 1. Make the voltage in the normal range 2. Remove the external force or install braking resistor

Fault Name	Power-supply fault
Fault Code	Err08
Reason	<ol style="list-style-type: none"> 1. The input voltage is out of range
Solution	<ol style="list-style-type: none"> 1. Make the voltage in the normal range

Fault Name	Under-voltage
Fault Code	Err09
Reason	<ol style="list-style-type: none"> 1. Instantaneous power-off 2. The input voltage is out of range 3. DC Bus voltage is abnormal 4. The rectifier bridge and buffer resistor are abnormal 5. The power board is abnormal 6. The control board is abnormal
Solution	<ol style="list-style-type: none"> 1. Fault Reset 2, 3. Make the voltage in the normal range 4, 5, 6. ask for technical support

Fault Name	Inverter over load
Fault Code	Err10
Reason	<ol style="list-style-type: none"> 1. The load is too heavy or motor blockage occurs 2. Power selection of inverter is too small
Solution	<ol style="list-style-type: none"> 1. Reduce the load, check the status of motor & machinery 2. Select bigger power inverter

Fault Name	Motor over load
Fault Code	Err11
Reason	<ol style="list-style-type: none"> 1. F0-10 and F0-11 are set improperly 2. The load is too heavy or motor blockage occurs 3. Power selection of inverter is too small
Solution	<ol style="list-style-type: none"> 1. Set F0-10 and F0-11 properly 2. Reduce the load, check the status of motor & machinery 3. Select bigger power inverter

Fault Name	Reserved
Fault Code	Err12

Fault Name	Output phase failure
Fault Code	Err13
Reason	<ol style="list-style-type: none"> 1. The connection between inverter and motor is abnormal 2. Output voltage unbalance during the motor running 3. The power board is abnormal 4. The IGBT module is abnormal
Solution	<ol style="list-style-type: none"> 1. Inspect whether motor damaged, insulation worn or cable damaged 2. Make sure the motor three phase winding is normal 3, 4. Ask for technical support

Fault Name	IGBT module over-heat
Fault Code	Err14
Reason	<ol style="list-style-type: none"> 1. Ambient temperature is too high 2. Air duct is blocked 3. Cooling fans are broken 4. Thermal resistor(temperature sensor) of the module is broken 5. IGBT module is broken
Solution	<ol style="list-style-type: none"> 1. Reduce the ambient temperature 2. Clear the air duct 3. Replace cooling fans 4, 5. Ask for technical support

Fault Name	External device fault
Fault Code	Err15
Reason	MI terminal receives an external fault signal generated by peripheral device
Solution	Find out the fault source, solve it and reset the inverter

Fault Name	Communication fault
Fault Code	Err16
Reason	<ol style="list-style-type: none"> 1. Master computer works abnormal 2. Communication cable is abnormal 3. Communication parameters (F1-09~F1-13) are set improperly
Solution	<ol style="list-style-type: none"> 1. Check the connection of master computer 2. Check the communication connection 3. Set communication parameters properly

Fault Name	Reserved
Fault Code	Err17

Fault Name	Current detection fault
Fault Code	Err18
Reason	1. Hall sensor is abnormal 2. The power board is abnormal
Solution	1. Check hall sensor and connection 2. Replace the power board
Fault Name	Reserved
Fault Code	Err19, Err20

Fault Name	EEPROM read/write fault
Fault Code	Err21
Reason	1. EEPROM chip is broken
Solution	1. Replace the control board

Fault Name	Inverter hardware fault
Fault Code	Err22
Reason	1. Over voltage 2. Over current
Solution	1. Handle as over voltage fault 2. Handle as over current fault

Fault Name	Motor short-circuit to ground
Fault Code	Err23
Reason	1. The motor is short-circuit to ground
Solution	1. Replace cables or motor

Fault Name	Current-limiting fault
Fault Code	Err40
Reason	1. Whether the load is heavy or the motor is blocked 2. Power selection of inverter is too small.
Solution	1. Reduce the load and detect the motor & machinery condition 2. Select bigger power inverter

Fault Name	Abnormal of high pressure
Fault Code	Err60
Reason	The real feedback pressure is higher than upper limitation pressure (F0-05)
Solution	<ol style="list-style-type: none"> 1. Wiring connection of pressure transducer is wrong or pressure transducer is damaged 2. Increase the value of F0-05 3. The pressure of pipe line is too high 4. Ask for technical support

Fault Name	Abnormal of low pressure
Fault Code	Err61
Reason	The real feedback pressure is lower than lower limitation pressure (F0-07)
Solution	<ol style="list-style-type: none"> 1. Wiring connection of pressure transducer is wrong or pressure transducer is damaged 2. Reduce the value of F0-07 3. Change the selection of F0-03 4. Connect the pressure transducer with master ARA388 5. Check whether the pipe line is broken somewhere 6. Open the valve and discharge the air inside the pipe line

Fault Name	Abnormal of lack water
Fault Code	Err63
Reason	ARA388/386 runs at 50Hz, no pressure from pipe line, and the running current is less than 80% of ARA388's rated current.
Solution	<ol style="list-style-type: none"> 1. Wiring connection of pressure transducer is wrong or pressure transducer is damaged. 2. Change the selection of F0-03 3. Connect the pressure transducer with master ARA388/386 4. Check whether the pipe line is broken somewhere 5. Open the valve and discharge the air inside the pipe line 6. Ask for technical support

7.2 Common Faults and Solutions

Fault	Reason	Solution
ARA388 stops after running for 10s. The indicator of "Auto" flakers	<ol style="list-style-type: none"> 1. Wiring connection of pressure transducer is wrong or pressure sensor is damaged. 2. Setting of F0-03 is wrong. 3. Without connecting pressure sensor for multiple pumps system. 4. No output 10V or 24V voltage from ARA388. 5. The valve for pressure transducer is not opened. 6. Air inside the pump or pipe line. 	<ol style="list-style-type: none"> 1. Check the wiring connection of pressure transducer or change a new transducer. 2. Change the setting of F0-03. 3. Connect pressure sensor with master ARA388/ARA386. 4. Replace a new control board. 5. Open the valve make pressure sensor is working. 6. Discharge the air in the pump or pipe line.
<p>Communication is abnormal under multiple pumps system.</p> <p>1, water pressure is low, cannot start next pump.</p> <p>2, The feedback pressure displayed on different ARA388 is unbalance, system cannot work normally.</p> <p>3, pumps cannot be alternated while set F0-25 properly.</p>	<ol style="list-style-type: none"> 1. Communication terminals S+, S- are not connected or wrongly connected. 2. F1-11 doesn't set as master (should be set as 1 or 2) 3. F1-11 is set the same value in different ARA388/386. 4. Communication terminals S+, S- are fault. 	<ol style="list-style-type: none"> 1. Connect S+, S- terminals correctly, and confirm the communication is normal. 2. Reset F1-11, make sure different ARA388 set different value 3. Initialize parameters to factory default (F0-24) 4. Ask for technical support.
Pump doesn't stop while nobody use the water	<ol style="list-style-type: none"> 1. The pipe line is broken, water leakage happen. 2. The one-way valve is broken. 3. The pressure transducer is broken. 	<ol style="list-style-type: none"> 1. Check the pipe line, valve and pressure transducer. 2. Increase the value of F0-16. 3. Change a new pressure transducer. 4. Ask for technical support.

<p>The displayed pressure values on ARA388/386 and pressure gauge (transducer) have big difference.</p>	<ol style="list-style-type: none"> 1. The measure range of F0-04 is set incorrect. 2. The pressure gauge (transducer) itself has big deviation, or it's broken. 	<ol style="list-style-type: none"> 1. Set a correct value in F0-04. 2. Set a suitable value to adjust the pressure. 3. Change a new pressure gauge (transducer). 4, Ask for technical support.
<p>ARA388/386 running at highest frequency level but the feedback pressure still very low.</p>	<ol style="list-style-type: none"> 1. Motor running direction is reversed. 2, Air inside the pump or pipe line. 3. The pressure gauge (transducer) is broken. 	<ol style="list-style-type: none"> 1. Change any two motor cables of output side, or change the value of F0-02. 2, Discharge the air in the pump or pipe line. 4. Change a new pressure gauge (transducer) 4, Ask for technical support.
<p>The frequency with big fluctuation, cannot keep stable while ARA388/ARA386 is running.</p>	<ol style="list-style-type: none"> 1, The dormancy frequency of F0-17 is set too big. 2, F0-05 is set too small. 3. The feedback pressure is abnormal. 	<ol style="list-style-type: none"> 1. Set suitable value of F0-17. 2. Set suitable value of F0-05. 3. Change a new pressure transducer.
<p>After pressing "RUN" button, the pump cannot run.</p>	<ol style="list-style-type: none"> 1. ARA388/ARA386 is under dormancy status. 2. F1-11 is not set suitable. 3. F1-00 is not set suitable. 4. Wiring connection of pressure transducer is incorrect, or the pressure transducer is broken. 	<ol style="list-style-type: none"> 1. Open the value to discharge the pipe line pressure. 2. Set suitable value in F1-00 and F1-11. 3. Reconnect the wiring connection of pressure transducer, or change a new pressure transducer. 4. Ask for technical support.

Chapter 8 Commissioning

8.1 One pump system

8.1.1 Wiring connection




Fig 8.1 Connect with pressure transducer




Fig 8.2 Connect with remote pressure gauge

8.1.2 Parameters setting

Function code	Default value	Set value	Description
F0-00	1	1	Single pump system
F0-01	0.4MPa	Customer set	1. Please set it correctly based on requested pressure, the unit is MPa, 1MPa=10bar. 2. Most of the family used systems, the pressure is 0.3~0.4MPa (3~4bar)
F0-02	80%	Customer set	Wake up pressure; it is the percentage of F0-01.
F0-03	0	0	It must be set as "0" while use 0~10V remote pressure gauge.
		1	It must be set as "1" while use 4~20mA pressure transducer.
F0-04	1.6MPa	1.6MPa	1. To set the maximum measure range of pressure transducer. 2. It must be set correctly, otherwise it may cause pressure is inaccurate.

For more parameters setting, please refer to chapter 5 in details.

8.1.3 process of fast operation and commissioning

1) Please check all the packing in KD388/KD386 is in good condition;

2) Wiring connection

- ① Main circuit, please connect the power supply to R, S, T (Single phase please connect R, T), and output side please connect U, V, W with pump.
- ② Connect the pressure transducer or remote pressure gauge to KD388 correctly, please refer to Fig 8.1 and Fig 8.2 for details.

3) After confirm the wiring connection, switch on the power supply.

- ① Set F0-00=0 (Manual operation mode) firstly, start ARA388 and check whether the running direction of pump is correct. If the running direction is incorrect, change the value of F0-02 or change any two motor cables connection.
- ② Under manual operation mode, discharge the air inside the pump and pipe line.

4) Check whether the pressure transducer is connected correctly.

- ① Set correct value in F0-04.
- ② Under manual operation mode, start ARA388/ARA386 and check whether the feedback pressure and real time display pressure on ARA388/ARA386 are the same. Long time press [▲][▼] to increase or decrease pump speed to check whether the feedback pressure is changed accordingly, if the feedback changes, it means the pressures transducer's wiring connection is correct,

5) Parameters setting

- ① While start ARA388 at the first time or forget some parameters, please set F0-24=1 to initialize the factory default value.
- ② Set parameters one by one based on the parameters list.

6) Routine inspection

- ① Check the constant water supply function, the water pressure can be keep at a stable level..
- ② Check the dormancy function, while close all the valves in the water system, ARA388/ARA386 can enter into dormancy status automatically.
- ③ Check the wake up function, under dormancy status, open some of valves in the water system, ARA388/ARA386 can wake up automatically.

NOTE: If any failures happen, please refer to chapter 7 to find the solutions.

8.2 Two pumps system

8.2.1 Wiring connection




Fig 8.3 Connect with pressure transducer




Fig 8.4 Connect with remote pressure gauge

8.2.2 Parameters setting

Function code	Default value	Set value		Description
F1-11	1	1# inverter	1	1# inverter (master), it must connect the pressure sensor. 2# inverter (slave / standby master), connect the pressure sensor. Warning: the address of each inverter cannot be the same, otherwise, the system will work abnormally.
		2# inverter	2	
F0-00	1	2		Multiple pumps system
F0-01	0.4MPa	Customer set		1. Please set it correctly based on requested pressure, the unit is MPa, 1MPa=10bar. 2. Most of the family used systems, the pressure is 0.3~0.4MPa (3~4bar)
F0-02	80%	Customer set		Wake up pressure; it is the percentage of F0-01.
F0-03	0	0		It must be set as "0" while use 0~10V remote pressure gauge.
		1		It must be set as "1" while use 4~20mA pressure transducer.
F0-04	1.6MPa	1.6MPa		1. To set the maximum measure range of pressure transducer. 2. It must be set correctly, otherwise it may cause pressure is inaccurate.
F0-25	300Min	Customer set		To set the running time as master pump, when time arrive, it switches to next pump as master. When set F0-25=0, this pump will only work as slave pump.

For more parameters setting, please refer to chapter 5 in details.

8.2.3 Process of fast operation and commissioning

1) Please check all the packing in ARA388/ARA386 is in good condition; 2) Wiring connection

- ① Main circuit, please connect the power supply to R, S, T (Single phase please connect R, T), and output side please connect U, V, W with pump.

- ② Connect the pressure transducer or remote pressure gauge to ARA388/ARA386 correctly, please refer to Fig 8.3 and Fig 8.4 for details.
- ③ Connect the communication cables, please select shielded twisted-pair cable to connect the S+ and S- of the two inverters together.

3) After confirm the wiring connection, switch on the power supply.

- ① Set F0-00=0 (Manual operation mode) firstly, start ARA388/ARA386 and check whether the running direction of pump is correct. If the running direction is incorrect, change the value of F0-02 or change any two motor cables connection.
- ② Under manual operation mode, discharge the air inside the pump and pipe line.

4) Check whether the pressure transducer is connected correctly.

- ① Set correct value in F0-04.
- ② Under manual operation mode, start ARA388/ARA386 and check whether the feedback pressure and real time display pressure on ARA388/ARA386 are the same. Long time press [▲] or [▼] to increase or decrease pump speed to check whether the feedback pressure is changed accordingly, if the feedback changes, it means the pressures transducer's wiring connection is correct (watch 1# pump).

5) Parameters setting

- ① While start ARA388/ARA386 at the first time or forget some parameters, please set F0-24=1 to initialize the factory default value.
- ② Set parameters one by one based on the above mentioned parameters list, F1-01 ~ F1-04 parameters are only needed to set in master inverter, but for two master system, it needs to set the parameters both in 1# inverter and 2 # inverter..

6) Routine inspection

Before inspecting, please start these two inverters, make them both work at running condition.

- ① Check the constant pressure water supply function, the water pressure can be keep at a stable level, 1# and 2# inverters display the same feedback pressure.
- ② Check the pump adding function, increase the water flow, while the master pump cannot get the target pressure, the slave pump will be started.
- ③ Check the pump remove function, decrease the water flow, while the master pump can get the target pressure, the slave pump will be stopped.
- ④ Check the dormancy function, while close all the valves in the water system, these two inverters can enter into dormancy status automatically.
- ⑤ Check the wake up function, under dormancy status, open some of valves in the water system, the master pump will be woken up by the setting wake up value of F0-02 automatically, then system enter into normal working conditions.

NOTE: If any failures happen, please refer to chapter 7 to find the solutions.

8.3.2 Parameters setting

Function code	Default value	Set value		Description
F1-11	1	1# inverter	1	1# inverter (master), it must connect the pressure sensor. 2# inverter (slave / standby master), connect the pressure sensor. 3# inverter (slave) Warning: the address of each inverter cannot be the same, otherwise, the system will work abnormally.
		2# inverter	2	
		3# inverter	3	
F0-00	1	2		Multiple pumps system
F0-01	0.4MPa	Customer set		1. Please set it correctly based on requested pressure, the unit is MPa, 1MPa=10bar. 2. Most of the family used systems, the pressure is 0.3~0.4MPa (3~4bar)
F0-02	80%	Customer set		Wake up pressure; it is the percentage of F0-01.
F0-03	0	0		It must be set as "0" while use 0~10V remote pressure gauge.
		1		It must be set as "1" while use 4~20mA pressure transducer.
F0-04	1.6MPa	1.6MPa		1. To set the maximum measure range of pressure transducer. 2. It must be set correctly, otherwise it may cause pressure is inaccurate.
F0-25	300Min	Customer set		To set the running time as master pump, when time arrive, it switches to next pump as master. When set F0-25=0, this pump will only work as slave pump.

For more parameters setting, please refer to chapter 5 in details.

8.3.3 Process of fast operation and commissioning

1) Please check all the packing in ARA388/386 is in good condition;

2) Wiring connection

- ① Main circuit, please connect the power supply to R, S, T (Single phase please connect R, T), and output side please connect U, V, W with pump.

- ② Connect the pressure transducer or remote pressure gauge to ARA388/ARA386 correctly, please refer to Fig 8.5 and Fig 8.6 for details.
- ③ Connect the communication cables, please select shielded twisted-pair cable to connect the S+ and S- of the three inverters together.

3) After confirm the wiring connection, switch on the power supply.

- ① Set F0-00=0 (Manual operation mode) firstly, start ARA388/ARA386 and check whether the running direction of pump is correct. If the running direction is incorrect, change the value of F0-02 or change any two motor cables connection.
- ② Under manual operation mode, discharge the air inside the pump and pipe line.

4) Check whether the pressure transducer is connected correctly.

- ① Set correct value in F0-04.
- ② Under manual operation mode, start ARA388/ARA386 and check whether the feedback pressure and real time display pressure on ARA388/ARA386 are the same. Long time press [▲] or [▼] to increase or decrease pump speed to check whether the feedback pressure is changed accordingly, if the feedback changes, it means the pressures transducer's wiring connection is correct (watch 1# pump).

5) Parameters setting

- ① While start ARA388/ARA386 at the first time or forget some parameters, please set F0-24=1 to initialize the factory default value.
- ② Set parameters one by one based on the above mentioned parameters list, F1-01 ~ F1-04 parameters are only needed to set in master inverter, but for two master system, it needs to set the parameters both in 1# inverter and 2 # inverter..

6) Routine inspection

Before inspecting, please start these three inverters, make them work at running condition.

- ① Check the constant pressure water supply function, the water pressure can be keep at a stable level, 1#, 2# and 3# inverters display the same feedback pressure.
- ② Check the pump adding function, increase the water flow, while the master one pump cannot get the target pressure, the slave pumps will be started one by one.
- ③ Check the pump remove function, decrease the water flow, while the master pump can get the target pressure, the slave pumps will be stopped one by one.
- ④ Check the dormancy function, while close all the valves in the water system, all of the three inverters can enter into dormancy status automatically.
- ⑤ Check the wake up function, under dormancy status, open some of valves in the water system, the master pump will be woken up by the setting wake up value of F0-02 automatically, then system enter into normal working conditions.

NOTE: If any failures happen, please refer to chapter 7 to find the solutions.

8.4 Four pumps system

8.4.1 Wiring connection




Fig 8.7 Connect with remote pressure transducer




Fig 8.8 Connect with remote pressure gauge

8.4.2 Parameters setting

Function code	Default value	Set value		Description
F1-11	1	1# inverter	1	1# inverter (master), it must connect the pressure sensor.
		2# inverter	2	2# inverter (slave / standby master), connect the pressure sensor.
		3# inverter	3	3# and 4# inverters (slave).
		4# inverter	4	Warning: the address of each inverter cannot be the same, otherwise, the system will work abnormally.
F0-00	1	2		Multiple pumps system
F0-01	0.4MPa	Customer set		1. Please set it correctly based on requested pressure, the unit is MPa, 1MPa=10bar. 2. Most of the family used systems, the pressure is 0.3~0.4MPa (3~4bar)
F0-02	80%	Customer set		Wake up pressure; it is the percentage of F0-01.
F0-03	0	0		It must be set as "0" while use 0~10V remote pressure gauge.
		1		It must be set as "1" while use 4~20mA pressure transducer.
F0-04	1.6MPa	1.6MPa		1. To set the maximum measure range of pressure transducer. 2. It must be set correctly, otherwise it may cause pressure is inaccurate.
F0-25	300Min	Customer set		To set the running time as master pump, when time arrive, it switches to next pump as master. When set F0-25=0, this pump will only work as slave pump.

For more parameters setting, please refer to chapter 5 in details.

8.3.3 Process of fast operation and commissioning

1) Please check all the packing in ARA388/386 is in good condition;

2) Wiring connection

- ① Main circuit, please connect the power supply to R, S, T (Single phase please connect R, T), and output side please connect U, V, W with pump.

- ② Connect the pressure transducer or remote pressure gauge to ARA388/ARA386 correctly, please refer to Fig 8.7 and Fig 8.8 for details.
- ③ Connect the communication cables, please select shielded twisted-pair cable to connect the S+ and S- of the four inverters together.

3) After confirm the wiring connection, switch on the power supply.

- ① Set F0-00=0 (Manual operation mode) firstly, start ARA388/386 and check whether the running direction of pump is correct. If the running direction is incorrect, change the value of F0-02 or change any two motor cables connection.
- ② Under manual operation mode, discharge the air inside the pump and pipe line.

4) Check whether the pressure transducer is connected correctly.

- ① Set correct value in F0-04.
- ② Under manual operation mode, start ARA388/386 and check whether the feedback pressure and real time display pressure on ARA388/ARA386 are the same. Long time press [▲] or [▼] to increase or decrease pump speed to check whether the feedback pressure is changed accordingly, if the feedback changes, it means the pressures transducer's wiring connection is correct (watch 1# pump).

5) Parameters setting

- ① While start ARA388/386 at the first time or forget some parameters, please set F0-24=1 to initialize the factory default value.
- ② Set parameters one by one based on the above mentioned parameters list, F1-01 ~ F1-04 parameters are only needed to set in master inverter, but for two master system, it needs to set the parameters both in 1# inverter and 2 # inverter..

6) Routine inspection

Before inspecting, please start these four inverters, make them work at running condition.

- ① Check the constant pressure water supply function, the water pressure can be keep at a stable level, 1#, 2#, 3# and 4# inverters display the same feedback pressure.
- ② Check the pump adding function, increase the water flow, while the master one pump cannot get the target pressure, the slave pumps will be started one by one.
- ③ Check the pump remove function, decrease the water flow, while the master pump can get the target pressure, the slave pumps will be stopped one by one.
- ④ Check the dormancy function, while close all the valves in the water system, all of the four inverters can enter into dormancy status automatically.
- ⑤ Check the wake up function, under dormancy status, open some of valves in the water system, the master pump will be woken up by the setting wake up value of F0-02 automatically, then system enter into normal working conditions.

NOTE: If any failures happen, please refer to chapter 7 to find the solutions.